



GUARD HARDENER® W

WATER REPELLENT

Surface Preparation

- Shake the product well before use.
- Always test on a small hidden portion of the substrate before applying.
- Use neat, do not dilute.

Application Procedure

1. Do not apply during rain, expected rain or very hot weather. Early morning is best. Always ensure the surface is dry, wait at least 48 hours after cleaning before sealing. Sweep the area prior to sealing.
2. Apply the product to a surface that is clean, dust-free, grease-free and dry.
3. Using a low-pressure sprayer, a short nap roller or a brush, apply to the surface.
4. The treated surface should be impregnated to saturation point, either in one application or in two applications “wet-on-wet”.
5. Do not over apply and eliminate any exceeding product before drying. Risk of white stains in case of excess.
6. Always apply from bottom to top.
7. Drying time: 24 hours.
8. Optimum effectiveness obtained after 2-3 days.
9. Indicative coverage is 5m²/Litre.