



Please Note

- 1. Shake the product well before use.
- 2. Always test on a small hidden portion of the substrate before applying.
- 3. Use neat, do not dilute.

Application procedure

- Do not apply during rain, expected rain or very hot weather. Early morning is best. Always ensure the surface is dry, wait at least 48 hours after cleaning before sealing.
- 2. Apply the product to a surface that is clean, dust-free, grease-free and dry.
- For smooth surfaces use 4-6mm nap roller. For textured surfaces use a 6-8mm nap roller. Apply in one uniform coat without excess. A wide brush can also be utilised.
- 4. Do not over apply and eliminate any exceeding product before drying.
- 5. Do not use a sprayer.
- 6. NOTE: In some cases, the product may leave white marks on the surface after application. This is normal and traces will disappear on drying.
- 7. Drying time: 24 hours.
- 8. Optimum effectiveness obtained after 7 days.
- 9. Indicative coverage is 10m2/Litre.