



# PROTECT GUARD® WF

## PREMIUM

### WET FINISH

#### Please Note

1. Shake the product well before use.
2. Always test on a small hidden portion of the substrate before applying.
3. Use neat, do not dilute.

#### Application procedure

1. Do not apply during rain, expected rain or very hot weather. Early morning is best. Always ensure the surface is dry, wait at least 48 hours after cleaning before sealing.
2. Apply the product to a surface that is clean, dust-free, grease-free and dry.
3. Using a foam roller or short-nap roller, apply in one thin layer without excess.
4. Do not over apply and eliminate any exceeding product before drying.
5. Do not use a sprayer.
6. Where necessary, apply a further layer to homogenise the wet effect.
7. Drying time: 24 hours.
8. Optimum effectiveness obtained after 7 days.
9. Indicative coverage is 12m<sup>2</sup>/Litre.